



Product Data Sheet

Kitchen Spray Filter



t-safe.com



Kitchen Spray Filter



Features

- Sterilising grade 0.2 µm rated hollow fiber membrane filter
- High capacity filter with up to 92 day life cycle
- Constant flow technology ensures optimal flow performance over life cycle
- Intelligent spray nozzle design ensures high velocity water delivery
- Replacement filter cartridge system extends use and reduces overall cost
- Dual functionality enables operation with or without filter installed
- Integral check valve prevents backflow contamination upstream

Order Information

Item	Code
Kitchen Spray Filter	02-803200
Replacement Filter	02-000153
Dummy Cartridge	02-000092

Technical Data

Max. operating pressure	5 bar
Max. operating temperature	60° C
Flow rate	12 L/min
Max. filter life cycle	92 days*
Connection	½ inch thread
Colour	Black & Chrome

Microbial retention

Sterilising grade membrane filter, effective against all waterborne pathogens. Independently tested and validated in accordance with ASTM F838 against:

- *Legionella pneumophila*
- *Pseudomonas aeruginosa*
- *Brevundimonas diminuta*

Approvals

ASTM F838-15A, KIWA, DVGW W270.
Compliant with EU food and drinking water directives.

* Dependent on local water quality and usage.

All information contained within this data sheet is based on the current knowledge and experience of T-safe. It is provided in good faith and is intended to serve only as a guideline for the selection and use of products. T-safe products should always be handled in accordance with the applicable Instruction for Use advice. The current data sheet is available at www.t-safe.com.